

TERAFLEX

INSTALLATION GUIDE

Installation Guide for the TJ Brake Light Extension Kit (BLET)

1. Remove the spare tire.



2. Release brake light wiring from retention clips to allow for extended length. Remove the bolts on the bottom of the brake light tower.



3. Place the brake light extension plate between rear tire mount and the brake light tower. The lower left side of the extension plate should match the contour of the rear tire mount.



4. Attach the bottom of the brake light extension plate to the tire

mount using the bolts removed in Step 1.



5. Connect the brake light tower to the top of the extension plate using the included hardware. Be sure to use a washer on both the top and bottom of the bolt.



6. Reinstall spare tire. (33-inch tire shown.)

Tera Manufacturing, Inc.
5251 South Commerce Dr.
Murray, Utah 84107
Phone/801.288.2585
Fax/801.713.2313
www.teraflex.biz

NOTE:

On the TJ Rubicon edition Wrangler, there is a factory spacer on the brake light mount that can be removed when installing the BLET.