

Miller Products
2065 S. Interstate 35W
Burleson, TX 76028



Voice: 817-447-4544
Fax: 817-447-8129
www.MP4x4.com

FRONT YJ, TJ, RECTANGULAR BUMPER INSTALLATION INSTRUCTIONS

1. Remove existing front bumper.
2. Using factory mounting bolts attach MP bumper.
3. Place included end caps on bumper ends and attach using the included carriage bolts and lock nuts.
4. If bumper wings (purchased separately) are to be used, omit step above and install per instructions.